

## POND PRO

North America's Pond Superstore

Born out of Ackenberry Trout Farm, Pond Pro is a family owned business. We have grown from a small pond supply store to a Canadian leader in pond supply, aeration systems, water fountains, and industrial water needs.

Be it designing a unique pond maintenance guide for a customer, offering advice on marketing products, or providing solutions for large scale water systems,

**OUR TEAM IS HERE TO HELP!**

GUARANTEED  
LOWEST  
PRICES **IN**  
**CANADA**

☎ 1-855-414-7663

✉ SALES@PONDPRO.CA

📍 CAMROSE, AB

🌐 PONDPRO.CA



# SEPTIC AERATION INSTRUCTION MANUAL

☎ 1-855-414-7663

✉ SALES@PONDPRO.CA

📍 CAMROSE, AB

🌐 PONDPRO.CA

# CONTENTS

- Can-Air ECO Diffuser
- Jebao PA-60 Air Compressor
- 25' 3/8" I.D Airline
- Required Fittings

## SUSPENSION OPTIONS

### *Suspend With Rope*

1. Swivel the check valve so it is straight up.
2. Use 2 carabiners or directly tie the rope to the holes on the sides of the ECO diffuser, then suspend the ECO diffuser.

### *Suspend With PVC Pipe*

1. Swivel the check valve so it is straight up.
2. Put a 1¼" coupler through the center hole, and add a nut to the bottom. Attach PVC pipe to the coupler to create a stick suspension. This makes pulling up the diffuser easier.


## INSTALLATION

### *2 Chamber System*

If you have a 2 chamber system, aeration can go in both the 1<sup>st</sup> and 2<sup>nd</sup> chamber, however the 2<sup>nd</sup> chamber will not have enough depth if there is a pump in it.


Systems with a gravity field outflow typically have a pump.

Pond Pro recommends aerating both chambers. Suspend the aeration in the 1<sup>st</sup> chamber a minimum of 1' off the bottom of the chamber, while aerating the 2<sup>nd</sup> chamber more vigorously.



### *3 Chamber System*

For proper aeration in a 3 chamber system, place the diffuser directly on the bottom of the middle chamber.



**! Do Not Disturb The Sludge**